



Drive adapter
 Standard configurations and
 machine specific executions upon request



Collet receptacle Hi-Q/ERAX32
 turning direction of tool receptacle
 opposite to drive turning direction



Collet receptacle Hi-Q/ERAX 32
 with internal thread

